



Classic Ellipse Transom Rail Mount Ski Tow Installation Instructions

(Part # 84502)



Product Safety Instructions

IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.

*To avoid a hazard to children, account for all parts and destroy all packing materials.

SERVICE

There are no user-serviceable parts inside. Opening unit will void warranty.

WARRANTY

For information on our warranty policy please visit our website at <http://www.itc-marine.com/resources/warranty/>

Installation Instructions:

Step 1: Drill two 3/8" holes 3.94" on center

Step 2: Remove hex nuts from posts

Step 3: Insert posts into holes drilled in step 1 making sure ski tow tongue is facing up

Step 4: Attach and tighten hex nuts back on posts

**This ski tow was designed to be used when welded into a 1" transom rail. It can be welded into any length rail.

