




# DuoFlo Sprayer Install Instructions

(Part #: 97040-XXXXY)

## PARTS/TOOLS NEEDED:

	Hole Saw Bit 2", 2 3/4" & 4"	Power Drill w/ Phillips Bit	Needle Nose Pliers
DuoFlo Includes: Nylon or SS Hose, Mesh Bag, Zip Ties & Mounting Screws	Not Provided	Not Provided	Not Provided

### IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.

\* To avoid a hazard to children, account for all parts and destroy all packing materials.

1. Determine the installation location. Use a hole saw to drill the appropriate hole size.

Part #	Mounting Type	Hole/Saw Bit Size
97040HSM	Horizontal Screw Mount	2"
97040HTM	Horizontal Toggle Mount	2 3/4"
97040VTM	Vertical Toggle Mount	4"

2. Attach the mesh bag with the zip tie. Use pliers to tighten zip tie securely to the shower cup. Cut the excess zip tie off with scissors.



3. Fish out the water line in the unit and attach hose to water supply line. Cinch the zip tie to the hose with needle nose pliers.



### 4. Screw Mount:

Mark the screw holes and predrill holes. Insert the holder with the bag into the hole. Screw the holder to the surface. Snap on bezel to the holder.



5. Attach cone connector on the hose to the spray head. Push hose and shower head into cup. Test with the water pump to ensure there are no leaks at the connections.



### 4. Toggle Mount:

Insert the holder with the bag into the hole. Tighten the toggles by using a drill or screw driver. Snap on bezel to the holder.



For warranty information please visit [www.itc-us.com](http://www.itc-us.com)

3030 Corporate Grove Dr. • Hudsonville • MI • 49426

Phone: 616-396-1355 • [www.itc-us.com](http://www.itc-us.com) • [sales@itc-us.com](mailto:sales@itc-us.com) • DOC# 710-00158 • Rev B: 12/11/20