



Rectangle Push Lens Light Installation Instructions

(Part #'s: 693RS-FF-KK-UML)

PARTS/TOOLS NEEDED:

				
Push Lens Light	Mounting Screws	Power Drill (Not Provided)	Marine Wire Connectors (Not Provided)	Silicone Sealant (Not Provided)


INSTALLATION CONSIDERATIONS

- Disconnect power before installing, adding or changing any component.
- To avoid a hazard to children, account for all parts and destroy all packing materials.
- It is recommended that fuse protection be added to the positive (+) input.
- All electrical connections should be made inside a watertight junction box.

1. Mark the corners and screw holes using the template below and drill pilot holes. Cut out the surface.




2. Wire the light based on the wiring diagram.



3. Attach light using the provided screws. Use silicone sealant around the wires and screw holes to prevent any ingress of water. Snap on decorative bezel.



4. Cutting template



For warranty information please visit www.itc-us.com

3030 Corporate Grove Dr. • Hudsonville • MI • 49426

Phone: 616-396-1355 • www.itc-us.com • sales@itc-us.com • DOC#: 710-00123 Rev A • 05/29/19